


PEDESTAL FAN

ASSEMBLY GUIDE

ASSEMBLING THE PEDESTAL FAN



STEP 1: Remove the washer and screw from the adjustable base pole.



STEP 2: Apply the base support weight to the base and install the adjustable base pole with the washer and base-locking screw.




STEP 3: Pull out the extension pole and secure it by tightening the height adjustment screw.




STEP 4: Remove large fixing screw and cap from the top of the extension pole.




STEP 5: Remove the small fixing screw and head tilt screw from the motor assembly unit bracket.




STEP 6: Attach the motor unit to the extension pole by installing the large fixing screw.




STEP 7: Reinstall the small fixing screw and head tilt screw on both sides of the motor unit bracket.




STEP 8: Install and tighten the large fixing screw cap to hold the motor unit in place.




STEP 9: Remove the four grill-locking screws from the motor assembly unit.




STEP 10: Install the rear grill with the handle at the top and facing out towards the motor assembly unit using the four grill-locking screws.




STEP 11: Remove the rubber part from the motor shaft and turn the groove of the motor shaft upwards.





STEP 12: Slide the fan blade unit onto the motor shaft, aligning and tightening the fan blade screw to the groove.



STEP 13: Hook the front grill onto the rear grill, aligning both screw holes at the bottom of each grill.



STEP 14: Install the grill screw and nut to lock the guards. Close the clips.




STEP 15: Plug in the fan. Unplug after use.

Note: Take care not to overtighten the base locking screw as this could cause damage to the base. Do not use tools to tighten the base-locking screw; the base should be attached firmly so that when the fan is fully assembled, the adjustable base pole and motor assembly do not wobble whilst the base remains flat.
Take care not to overtighten the height adjustment screw as this may damage the pedestal fan.

USING THE PEDESTAL FAN



STEP 1: To adjust tilting angle, loosen the head tilt screw. Tighten again at the desired tilt.



STEP 2: To switch the fan on, select speeds I-III on the adjustable cooling speed dial. To switch fan off, select 0.



STEP 3: Push the oscillation switch down to activate oscillation function. Pull the oscillation switch up for normal operation.

Caution: Do not cover the fan head.
This is not a desk fan. Do not place the fan onto a desk as this could affect the stability of the product.

Beldray est 1872 [®]