

# Beldray<sup>est 1872</sup>®

Our efficient,  
lightweight &  
compact  
air purifier



**CLEAN AIR**  
**PURIFIER**  
INSTRUCTION MANUAL



[www.beldray.com](http://www.beldray.com)

Please read all of the instructions carefully and retain for future reference.

## **Safety Instructions**

When using electrical products, basic safety precautions should always be followed.

Check that the voltage indicated on the rating plate corresponds with that of the local network before connecting the product to the mains power supply.

Children younger than 3 years old should be kept away from the product unless continuously supervised.

Children aged from 3 years and less than 8 years should only switch on/off the product, provided that it has been placed or installed in its intended operating position and they have been given supervision or instruction concerning the use of the product in a safe way and understand the hazards involved.

Children aged from 3 years and less than 8 years should not plug in, regulate or clean the product or perform user maintenance.

Children aged from 8 years and people with reduced physical, sensory or mental capabilities or lack of experience and knowledge can use this appliance, only if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children should not carry out cleaning or user maintenance without supervision.

Children should be supervised to ensure that they do not play with the product.

This product is not a toy.

This product contains no user serviceable parts. If the power supply cord, plug or any part of the product is malfunctioning or if it has been dropped or damaged, only a qualified electrician should carry out repairs. Improper repairs may place the user at risk of harm.

Keep the product and its power supply cord out of the reach of children.

Keep the product and its power supply cord away from heat or sharp edges that could cause damage.

Keep the power supply cord away from any parts of the product that may become hot during use.

Keep hands, fingers, hair and any loose clothing away from the rotating parts of the product.

Do not immerse the product in water or any other liquid.

Do not operate the product with wet hands.

Do not leave the product unattended whilst connected to the mains power supply or when in use.

Do not remove the product from the mains power supply by pulling the cord; switch it off and remove the plug by hand.

Do not use the product for anything other than its intended use.

Do not cover the product.

Do not use the product outdoors.

Do not move the product whilst it is in use.

Do not shake the product.

Do not put objects into any of the openings.

Do not clean the product with abrasive chemicals or materials such as scourers, as they may damage it.

Do not spray insecticide or chemical solvents on the product.

Always unplug the product after use and before any cleaning or maintenance.

Always use the product on a flat, stable surface.

Use of an extension cord with the product is not recommended.

This product should not be operated by means of an external timer or separate remote control system, other than that supplied with this product.

This product is intended for domestic use only. It should not be used for commercial purposes.

**Warning:** If a strong odour is emitted from the product, turn the unit off and unplug it from the mains power supply.

## Care and Maintenance

**STEP 1:** Unplug the air purifier from the mains power supply before attempting any cleaning or user maintenance.

**STEP 2:** Wipe the air purifier with a soft, damp cloth and dry thoroughly.

**Note:** Do not use flammable liquid, abrasive cleaning solvents, polishes or scouring pads to clean the air purifier, as this may cause damage.

The power indicator light will flash continually when the filter needs to be replaced. Follow the instructions in the section entitled 'Replacing the Filter'. After replacement, press and hold 'TIMER' for approx. 3 seconds; the power indicator light will stop flashing.

This will start an internal timer; when it elapses, the power indicator light will flash again to indicate a new filter is required.

## Description of Parts



- |                                                     |                                            |
|-----------------------------------------------------|--------------------------------------------|
| 1. Total Air Purifier main unit                     | f) Timer setting indicator light (2, 4, 8) |
| 2. Power adaptor                                    | g) Mood light button                       |
| 3. Control panel                                    | 4. Base cover                              |
| a) Power button ( <b>ON/OFF</b> )                   | a) Power adaptor inlet                     |
| b) Power indicator light                            | b) Base cover lid                          |
| c) Fan speed button ( <b>FAN</b> )                  | c) Filter                                  |
| d) Speed setting indicator light ( <b>L, M, H</b> ) | e) Timer button ( <b>TIMER</b> )           |
| e) Timer button ( <b>TIMER</b> )                    |                                            |

## Instructions for Use

### Before First Use

**Note:** The filter is originally provided packed in a poly bag; remove this before first use.

**Warning:** Before removing the filter from the air purifier, check that it is switched off and unplugged from the main power supply.

## To remove the poly bag, follow these instructions:

**STEP 1:** To remove the filter from the air purifier, invert the air purifier and remove the base cover lid by twisting in an anticlockwise direction and pulling away from the air purifier main unit.

**STEP 2:** Remove the filter by lifting up and away from the air purifier main unit.

**STEP 3:** Remove the polybag from the filter, then replace the filter back into their air purifier main unit.

**STEP 4:** Replace the base cover lid, checking that the tabs are aligned with those on the base cover and lock into place by pressing downwards and rotating in a clockwise direction until secure.

## Using the Total Air Purifier

**STEP 1:** Invert the air purifier main unit and insert the power adaptor into the power adaptor inlet.

**STEP 2:** Place the air purifier on a flat, stable surface at a height that is comfortable for the user. Plug in the power adaptor into the mains power supply.

**STEP 3:** Turn the air purifier on by pressing '**ON/OFF**' on the control panel. The air purifier will beep once and start to function. Speed setting indicator light 'L' (signalling the lowest speed setting) will illuminate on the control panel.

**STEP 4:** To select another speed setting, press '**FAN**' on the control panel. There are three speed settings to choose from: Low (L), Medium (M), and High (H). The speed setting indicator lights will show the selected speed setting.

**STEP 5:** Turn off the air purifier by pressing '**ON/OFF**'.

**Note:** Make sure the air purifier is placed at least 30 cm away from any wall or piece of furniture.

The max. applicable area of use is 20 m<sup>2</sup> (225 ft<sup>2</sup>).

**Warning:** Do not position the air purifier directly under furniture or objects that may obstruct the exhaust air flow.

Do not use the air purifier near any source of heat.

## Using the Timer Function

**STEP 1:** To turn on the timer function, press '**TIMER**' on the control panel.

**STEP 2:** Select the desired timer function setting by pressing the timer function button on the control panel. Pressing the button will switch in between the air purifier timer function settings '2 hours' (2), '4 hours' (4) and '8 hours' (8). The timer function indicator light will show the selected timer setting.

The air purifier will automatically switch off after the selected time has expired.

## Using the Mood Light Function

**STEP 1:** To turn on the mood light function, press '**MOOD**' on the control panel.

**STEP 2:** Press '**MOOD**' again to cycle through the LED light colour options. There are 3 LED light colour options to choose from: green, orange and red. The LED mood light will automatically illuminate in the selected colour.

## Using Ambient Mode

Ambient mode sets the air purifier to the lowest speed setting with all indicator lights switched off.

**STEP 1:** To turn on ambient mode, press and hold '**FAN**' for approx. 5 seconds until the air purifier beeps once.

**STEP 2:** Deactivate ambient mode by pressing any button.

## Using the Control Lock

Use the control lock to temporarily lock the control panel and deactivate the function buttons.

**STEP 1:** To turn on the control lock, press and hold '**ON/OFF**' for approx. 5 seconds until the air purifier beeps once.

**STEP 2:** Deactivate the control lock by pressing and holding '**ON/OFF**' for approx. 5 seconds.

## Replacing the Filter

The power indicator light will flash when the filter needs to be replaced.

**STEP 1:** To remove the filter from the air purifier, invert the air purifier and remove the base cover lid by twisting in an anticlockwise direction and pulling away from the air purifier main unit.

**STEP 2:** Remove the exhausted filter by lifting up and away from the air purifier main unit.

**STEP 3:** Place a new filter back into the air purifier main unit.

**STEP 4:** Replace the base cover lid, checking that the tabs are aligned with those on the base cover and lock into place by pressing downwards and rotating in a clockwise direction until secure.

## Troubleshooting

Problem	Possible Cause	Solution
The air purifier will not switch on.	The air purifier is not connected to the mains power supply.	Plug in and switch on the air purifier at the mains power supply.
A strong odour is being emitted from the air purifier.	The surrounding area is not suitably ventilated.  The filter is exhausted and needs to be replaced.	Unplug the air purifier from mains power supply and ventilate the area.  Check if the power indicator light is flashing and replace the filter if necessary.
The air purifier is making a high-pitched sound.	The poly bag has not been removed from the filter  The filter is exhausted and needs to be replaced.	Check if the poly bag has been removed and remove if necessary.  Check if the power indicator light is flashing and replace the filter if necessary.
There are changes in humidity and temperature.	The area of the room is too large.	Use the air purifier in a room with an area of no bigger than the max. applicable area (20 m <sup>2</sup> ).

## Specifications

Product code: EH3349  
 Input: 220-240 V ~ 50 Hz  
 Output: 22 W



## Connection to the mains

Please check that the voltage indicated on the product corresponds with your supply voltage.

### Important

As the colours in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, please proceed as follows:

The wires in the mains lead are coloured in accordance with the following code:

Blue Neutral (N)

Brown Live (L)

FOR UK USE ONLY - Plug fitting details  
(where applicable).

The wire coloured BLUE is the NEUTRAL and must be connected to the terminal marked N or coloured BLACK.


The wire coloured BROWN is the LIVE wire and must be connected to the terminal marked L or coloured RED.

On no account must either the BROWN or the BLUE wire be connected to the EARTH terminal ( $\perp$ ).

Always ensure that the cord grip is fastened correctly.

The plug must be fitted with a fuse of the same rating already fitted and conforming to BS 1362 and be ASTA approved.

If in doubt consult a qualified electrician who will be pleased to do this for you.



### Non-rewireable mains plug

If your appliance is supplied with a non-rewireable plug fitted to the mains lead and should the fuse need replacing, you must use an ASTA approved one (conforming to BS 1362 of the same rating).

If in doubt, consult a qualified electrician who will be pleased to do this for you.

If you need to remove the plug - DISCONNECT IT FROM THE MAINS and then cut it off the mains lead and immediately dispose of it safely. Never attempt to reuse the plug or insert it into a socket outlet as there is a danger of an electric shock.



**UP Global Sourcing UK Ltd.,  
UK. Manchester OL9 0DD.  
Germany. 51149 Köln.**

If this product does not reach you in an acceptable condition please contact our Customer Services Department at [www.beldray.com](http://www.beldray.com).

Please have your delivery note to hand as details from it will be required.

If you wish to return this product please return it to the retailer from where it was purchased with your receipt (subject to their terms and conditions).

## **Guarantee**

All products purchased as new carry a manufacturer's guarantee; the time period of the guarantee will vary dependent upon the product. Where reasonable proof of purchase can be provided, Beldray will provide a standard 12 month guarantee with the retailer from the date of purchase. This is only applicable when products have been used as instructed for their intended, domestic use. Any misuse or dismantling of products will invalidate any guarantee.

Under the guarantee, we undertake to repair or replace free of any charge any parts found to be defective. In the event that we cannot provide an exact replacement, a similar product will be offered or the cost refunded. Any damages from daily wear and tear are not covered by this guarantee, nor are consumables such as plugs, fuses etc.

Please note that the above terms and conditions may be updated from time to time and we therefore recommend that you check these each time you revisit the website.

Nothing in this guarantee or in the instructions relating to this product excludes, restricts or otherwise affects your statutory rights.

The crossed out wheellie bin symbol on this item indicates that this appliance needs to be disposed of in an environmentally friendly way when it becomes of no further use or has worn out. Contact your local authority for details of where to take the item for recycling.





\*To be eligible for the extended guarantee, go to **www.beldray.com** and register your product within 30 days of purchase.

Find us on 

[www.facebook.com/Beldray](https://www.facebook.com/Beldray)



Manufactured by:  
UP Global Sourcing UK Ltd.,  
**UK.** Manchester OL9 0DD.  
**Germany.** 51149 Köln.

[www.beldray.com](https://www.beldray.com)

©Beldray Trademark. All rights reserved.

CD121120/MD000000/V1