

CARPET SWEEPER

QUICK START GUIDE

Please retain instructions for future reference.

CAUTION


The Carpet Sweeper is not designed to replace a vacuum cleaner.

The Carpet Sweeper should only be used to clean small areas of hard or soft floors.

Do not use the Carpet Sweeper with water or any other liquid.

Keep out of the reach of children.

DESCRIPTION OF PARTS



- A) Carpet Sweeper head
- B) Pole (qty. 3)
- C) Handle
- D) Brush tool

GETTING STARTED

Remove all packaging from the components.

Separate the Carpet Sweeper head from the poles.

Check for signs of damage before first use.

CARE AND MAINTENANCE

Empty the Carpet Sweeper after every use.

Regularly check the brushes on the underside of the Carpet Sweeper head. Use the brush tool provided to remove trapped debris.

Wipe the Carpet Sweeper with a soft, damp cloth and allow to dry.

Do not immerse the Carpet Sweeper in water or any other liquid.

Never use harsh or abrasive cleaning detergents or scourers to clean the Carpet Sweeper as this could cause damage.

ASSEMBLING THE CARPET SWEEPER

STEP 1: Screw the poles (B) together by positioning one pole inside the other and twisting in a clockwise direction until secure. Repeat to connect the third pole.

STEP 2: Screw the assembled poles into the Carpet Sweeper head (A) by twisting in a clockwise direction until secure.

STEP 3: Screw the handle (C) to the top of the assembled poles by twisting in a clockwise direction until secure.

DISASSEMBLING AND STORING THE CARPET SWEEPER

STEP 1: Detach the poles from the Carpet Sweeper head (A) by twisting in an anticlockwise direction and lifting up and away.

STEP 2: Separate the poles (B) by twisting each section in an anticlockwise direction.

DIRECTIONS FOR USE

STEP 1: Holding the handle firmly, steadily push the Carpet Sweeper across a small area of hard or soft floor to pick up debris.

STEP 2: After use, empty the Carpet Sweeper by turning the Carpet Sweeper head (A) upside down. Push the indicated areas on the underside of the Carpet Sweeper head to release the lid. Carefully empty the contents into a suitable bin.

STEP 3: To close the lid, push it down on both sides until it clicks shut.

If this product does not reach you in an acceptable condition please contact our Customer Services Department at **www.beldray.com**. Please have your delivery note to hand as details from it will be required. If you wish to return this product, please return it to the retailer from where it was purchased with your receipt (subject to their terms and conditions).

Go to **www.beldray.com** and search **LA024855PURWK2** to access the instruction manual for your product.



Distributed by:
UP Global Sourcing UK Ltd.,
UK. Manchester OL9 0DD.
Germany. 51149 Köln.
Made in China.

©Beldray Trademark. All rights reserved.

*To be eligible for the extended guarantee, go to **www.beldray.com** and register your product within 30 days of purchase.